

## HOSE INSERT

To help prevent water and particulates from entering your vacuum pump, the small hose should be inserted into the large hose. See pictures below.

To do this, take the small hose and coat one end (approx. 4”) with vegetable or mineral oil. Then simply insert the oil-coated end into the large hose until it is housed completely within the large hose.

